



BMW M2 G87 Carbon Fiber Spoiler with LED light Assembly Instruction

- 1. Place a few pieces of protective tape on the furthest ends of the trunk lid.
- 2. Place the trunk lid mount on the tape and mark the holes.
- 3. Drill through the trunk lid as marked. Use a 6 mm drill bit.
- 4. From the inner side of the trunk lid widen the drilled holes, but only the ones located closer to the center of the lid. Use a 19 mm wide hole saw. Drill out two of the three sheet metal layers with a hole saw.

























- 5. Take the right-side gasket (characterized by an additional hole).
- 6. Put the gasket on the right side of the trunk lid so that the holes in the gasket are aligned with the holes in the lid.
- 7.Drill a hole through the trunk lid where there is an additional hole on the gasket. Use an 8 mm drill bit.
- 8.Insert the grommet gasket into the drilled hole.
- 9.Place the right-side gasket to match the holes and place the trunk lid mount over it.












+48 14 307 06 04 sales@maxtondesign.eu








- 12. Screw the trunk lid mount, with the gasket in place, to the trunk lid.
- 13. To attach the external screws, cut the nuts appropriately to fit the trunk lid reinforcements.
















Video assembly instructions
















- 14. Attach the right mounting bracket to the spoiler and route the cable through the hole.
- 15. Prepare the mounting screws and washers. Apply a low-tear locking adhesive to the thread.
- 16. Screw the mounting brackets to the mounts on the spoiler.
- 17. Put the plugs into the holes in the trunk lid.




























into the holes.





20. Screw both parts together, apply low-tear safety adhesive to the screw threads.

21. Connect the spoiler cable with the control box

